

Product Data Sheet

| | | | | | |
|--|---|-------|------|--|-------|
| Model identifier(s): | HL 1120 CB | | | | |
| Item | Symbol | Value | Unit | Item | Unit |
| Heat output | | | | Type of heat input, for electric storage local space heaters only | |
| Nominal heat output | P_{nom} | 2.0 | kW | manual heat charge control, with integrated thermostat | N / A |
| Minimum heat output (indicative) | P_{min} | 1.0 | kW | manual heat charge control with room and / or outdoor temperature feedback | N / A |
| Maximum continuous heat output | $P_{max,c}$ | 2.0 | kW | electronic heat charge control with room and / or outdoor temperature feedback | N / A |
| Auxiliary electricity consumption | | | | fan assisted heat output | N / A |
| At nominal heat output (fan motor) | el_{max} | 0.025 | kW | Type of heat output / room temperature control | |
| At minimum heat output (fan motor) | el_{min} | 0.025 | kW | single stage heat output and no room temperature control | no |
| In standby mode | el_{SB} | N/A | W | Two or more manual stages, no room temperature control | no |
| | | | | with mechanic thermostat room temperature control | yes |
| | | | | with electronic room temperature control | no |
| | | | | electronic room temperature control plus day timer | no |
| | | | | electronic room temperature control plus week timer | no |
| | | | | Other control options | |
| | | | | room temperature control, with presence detection | no |
| | | | | room temperature control, with open window detection | no |
| | | | | with distance control option | no |
| | | | | with adaptive start control | no |
| | | | | with working time limitation | no |
| | | | | with black bulb sensor | no |
| Contact details | C. Bomann GmbH, Heinrich-Horten-Str. 17, 47906 Kempen / Germany | | | | |
| N/A = Not applicable | | | | | |